



Date: 08/ 09/ 20

Issue: 3

Fitting Instruction Sheet

Manufacturer: **Kawasaki**

Shock Type: **0**

Model: **Z 650**

Part Code: **NTR R2/3 40/14 Remote Reservoir**

Year: **2017 -2020**

Use: **Road**

The shock should be installed so that the remote reservoir exits at the rear of the shock body as shown. Feed the remote reservoir and hose around to the left hand side



The remote reservoir should be mounted to the left hand frame rail using the supplied bracket. If your shock has the optional hydraulic preload adjuster this should be mounted on the remote reservoir using the supplied clamp.

