



Date: 25/ 08/ 20

Issue: 1

Fitting Instruction Sheet

Manufacturer: KTM

Shock Type: NTBKKT11_

Model: 390 Adventure

Part Code: NTR R1 40/14

Year: 2020

Use: Road

If your shock has the optional hydraulic preload adjuster, the hydraulic adjuster body should be mounted to the pillion footrest/exhaust hanger on the right hand side using the supplied bracket as shown. Secure the hose using the supplied zip ties.

The shock should be installed such that the hydraulic preload hose exits from the hydraulic cylinder at the 10 O'clock position when viewed from above.



