



Date: 17/ 10/ 19

Issue: 1

Fitting Instruction Sheet

Manufacturer: Suzuki

Shock Type: NTBKS65_H

Model: GSX-S 750

Part Code: NTR R2/3 40/14 Remote Reservoir

Year: 2017 - 2019

Use: Road

The shock should be installed with the remote reservoir hose exiting at the rear of the shock body (6 o'clock). Mount the remote reservoir using the supplied bracket between the subframe and pillion footrest hanger using the new longer M8 bolts.



If your shock is fitted with the optional hydraulic preload adjuster, mount the hydraulic adjuster body with the supplied bracket using the exhaust hanger bolt as shown. Secure the hydraulic hose to the back of the footrest hanger with the small zip tie.

