



Date: 18/ 10/ 19

Issue: 1

## Fitting Instruction Sheet

Manufacturer: **Suzuki**

Shock Type: **NTBKS65\_**

Model: **GSX-S 750**

Part Code: **NTR R1 40/14**

Year: **2017 - 2019**

Use: **Road**

The shock should be installed with the hydraulic preload adjuster hose exiting on the left hand side of the shock body (3 o'clock). Mount the hydraulic adjuster body with the supplied bracket using the exhaust hanger bolt as shown. Secure the hydraulic hose to the back of the footrest hanger with the small zip tie.

